

AGRICULTURAL

1. Substitute rusted G.I suction/delivery pipes by low friction rigid PVC pipes of correct diameter.
2. Replace substandard foot valve by ISI marked foot valve.
3. Replace substandard pumpsets by energy efficient pumpsets.
4. Use correct size pumpsets and associated accessories.
5. Provide and maintain capacitors in good condition.
6. Avoid operation under low voltage conditions.
7. Install, repair pumpset motors and wiring by competent electrical personnel.
8. Ensure adequate water availability when pumpsets are operated.
9. Avoid rewinding of motors.

